



DesignMax DM10S-SUB

Surface-mount Subwoofer

Installation Guide	Monteringsveiledning32
Guía de instalación	Instrukcja montażu
Notice d'installation	安装指南
Installationsanleitung	安裝指南
Guida all'installazione22	設置ガイド52
Installatiehandleiding 27	ﻠﻴﻞ اﻟﺘﺮﻛﻴﺐ

Please read and keep all safety and use instructions.

This product is intended for installation by professional installers only! This document is intended to provide professional installers with basic installation and safety guidelines for this product in typical fixed-installation systems. Please read this document and all safety warnings before attempting installation.

Do not attempt to service this product yourself. Refer all servicing to authorized service centers, installers, technicians, dealers or distributors. To contact Bose Professional or to find a dealer or distributor near you, visit **PRO.BOSE.COM**.

- Read these instructions.
- 2. Keep these instructions.
- Heed all warnings.
- 4. Follow all instructions.
- 5. Do not use this apparatus near water.
- 6. Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produces heat.
- 9. Only use attachments/accessories specified by the manufacturer.



WARNINGS/CAUTIONS





This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.

- All Bose products must be installed in accordance with local, state, federal and industry
 regulations. It is the installer's responsibility to ensure installation of the loudspeakers
 and mounting system is performed in accordance with all applicable codes, including
 local building codes and regulations. Consult the local authority having jurisdiction
 before installing this product.
- Unsafe mounting or overhead suspension of any heavy load can result in serious
 injury or death, and property damage. It is the installer's responsibility to evaluate
 the reliability of any mounting method used for their application. Only professional
 installers with the knowledge of proper hardware and safe mounting techniques should
 attempt to install any loudspeaker overhead.
- Do not mount the product in locations where it may be exposed to water or condensation.
- This product is not intended for installation or use in indoor water facility areas (including, without limitation, indoor pools, indoor water parks, hot tub rooms, saunas, steam rooms and indoor skating rinks).
- Do not mount on surfaces that are not sturdy, or that have hazards concealed behind them, such as electrical wiring or plumbing. If you are not sure about installing the bracket, contact a qualified professional installer. Ensure the bracket is installed according to local building codes.
- Use only the hardware and accessories included or specified by Bose for use with DesignMax DM10S-SUB loudspeakers. Hardware for securing the loudspeaker to the mounting surface is not supplied. For information on compatible accessories, see the product's technical data sheet at PRO.BOSE.COM.
- Keep the product away from fire and heat sources. Do not place naked flame sources, such as lighted candles, on or near the product.
- · Do not make unauthorized alterations to this product.
- The DesignMax DM10S-SUB wall mounting bracket is only for use with model DM10S-SUB.
- Clean speakers using only a dry cloth. Do not expose loudspeaker to soap, detergent, mineral oil, alcohol or other cleaning agents or chemicals.

Product Ratings:

Input Voltage: 70V/100V Impedance: 8Ω , 250 W

Current or Power: (70V): 20W, 40W, 80W, 150W; (100V): 40W, 80W, 150W

Regulatory Information



This product conforms to all applicable EU directive requirements. The complete declaration of conformity can be found at: **www.Bose.com/compliance**.




This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

China Restriction of Hazardous Substances Table

Names and Contents of Toxic or Hazardous Substances or Elements							
	Toxic or Hazardous Substances and Elements						
Part Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent (CR(VI))	Polybrominated Biphenyl (PBB)	Polybrominated diphenylether (PBDE)	
PCBs	Х	0	0	0	0	0	
Metal Parts	Х	0	0	0	0	0	
Plastic Parts	0	0	0	0	0	0	
Speakers	Х	0	0	0	0	0	
Cables	Х	0	0	0	0	0	

This table is prepared in accordance with the provisions of SJ/T 11364.

O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.





Taiwan Restriction of Hazardous Substances Table

Equipment name: DesignMax DM10S-SUB, Type designation: 829380							
		Restricted substances and its chemical symbols					
Unit	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr+6)	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)	
PCBs	-	0	0	0	0	0	
Metal Parts	-	0	0	0	0	0	
Plastic Parts	0	0	0	0	0	0	
Speakers	-	0	0	0	0	0	
Cables	-	0	0	0	0	0	

Note 1: "o" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.

Note 2: The "-" indicates that the restricted substance corresponds to the exemption.

Date of Manufacture: The eighth digit in the serial number indicates the year of manufacture; "7" is 2007 or 2017.

China Importer: Bose Electronics (Shanghai) Company Limited, Part C, Plant 9, No. 353 North Riying Road, China (Shanghai) Pilot Free Trade Zone

EU Importer: Bose Products B.V., Gorslaan 60, 1441 RG Purmerend, The Netherlands

Mexico Importer: Bose de México, S. de R.L. de C.V., Paseo de las Palmas 405-204, Lomas de Chapultepec, 11000 México, D.F. For importer & service information: +5255 (5202) 3545

Taiwan Importer: Bose Taiwan Branch, 9F-A1, No. 10, Section 3, Minsheng East Road, Taipei City 104, Taiwan. Phone Number: +886-2-2514 7676

Bose and DesignMax are trademarks of Bose Corporation.

Bose Corporation Headquarters: 1-877-230-5639

©2019 Bose Corporation. No part of this work may be reproduced, modified, distributed or otherwise used without prior written permission.


Warranty Information


This product is covered by a limited warranty.

For warranty details, visit **PRO.BOSE.COM**.

PRO.BOSE.COM Overview

Package Contents












Product Dimensions







Technical Specifications

For additional specifications, see the DesignMax DM10S-SUB technical data sheet at ${\bf PRO.BOSE.COM}.$

Physical	
Product Dimensions	Height: 502 mm (19.78 in)
	Width: 316 mm (12.45 in)
	Depth: 323 mm (12.70 in)
Net Weight, Loudspeaker with grille and bracket	16.10 kg (35.5 lb)
Shipping Weight	18.82 kg (41.5 lb)

Important Installation Information



This product is intended for indoor use only.

It is the installer's responsibility to ensure installation of the loudspeakers and mounting system is performed in accordance with all applicable codes, including local building codes and regulations. Consult the local authority having jurisdiction before installing this product.

It is the responsibility of the installer to ensure the safety of the loudspeaker installation. Failure to properly install the loudspeaker could result in damage, injury, or death.

Do not mount the product in locations where it may be exposed to water or condensation.



Do not mount the product in locations where condensation may occur. This product is not intended for installation or use in indoor water facility areas (including, without limitation, indoor pools, indoor water parks, hot tub rooms, saunas, steam rooms and indoor skating inks).

Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produces heat.

The backware for securing the laudspeaker to the mounting surface.

The hardware for securing the loudspeaker to the mounting surface is not supplied. Consult a building professional for the proper mounting hardware before installing the loudspeaker.



Do not mount on surfaces that are not sturdy, or that have hazards concealed behind them, such as electrical wiring or plumbing. If you are not sure about installing the bracket, contact a qualified professional installer. Ensure the bracket is installed according to local building codes.

Wiring the Loudspeaker


Wire Gauge


The DesignMax DM10S-SUB loudspeaker is designed to work with 18 AWG (0.8 mm²) to 14 AWG (2.1 mm²) size wire only.

Connection Diagrams


Expose six millimeters (¼ inch) of bare wire to attach to the terminals.

Note: The loudspeaker is not rated for use with a rigid conduit. The loudspeaker is suitable for a flexible conduit or wiring connection only.





Loudspeaker Settings



70V				
20W	40W	80W	150W*	8Ω
40W	80W	150W	NC**	812
100V				

^{*} Factory default

Transformer Tap Setting


Set tap by turning. Use a flat head screwdriver.

Using a Safety Cable

Some regional construction codes require the use of a secondary method of securing loudspeakers to support structures to provide additional safety. Choose a mounting position, method, and hardware consistent with local building codes and regulations.

A safety cable can be attached to the loudspeaker using the threaded insert on the back of the enclosure.

The insert is sized for an M8 screw (not included) with a depth of 15 millimeters (0.59 inches).




^{**} NC: No Connection (do not use)

PRO.BOSE.COM Installation

Installation Options

There are two pairs of slots used to secure the loudspeaker to the mounting bracket, located on the back and side of the loudspeaker. There are two different loudspeaker mounting positions: horizontal and vertical. See the table to the right to choose the installation option best suited for your installation.

Note: Installation in close proximity to cooking surfaces where the loudspeaker may be directly exposed to cooking oils, such as in commercial cooking environments, may decrease the performance or functionality of the loudspeaker.




Installing the Bracket

Note: When choosing an installation location, at least one of the mounting bracket's attachment points must be secured to a support structure. Attachment points not secured to a support structure must be secured using appropriate hardware for the installation. Choose fasteners that are consistent with all local building codes and requirements.


Note: Choose appropriate fasteners to support the weight of the loudspeaker (16.10 kg [35.5 lb]).

- 1. Mark the drill holes.
- 2. Drill four holes (sized for appropriate fasteners) into the wall.
- 3. Secure the bracket to the wall with four screws (not included). Note: Use M6 or ¼-inch sized screws.



Wiring the Connector

- 1. Feed the wires through the center hole of the bracket.
- 2. Remove the connector from the loudspeaker.
- 3. Wire the connector. For wiring information, see **Wiring the Loudspeaker** on page 4.



Installation PRO.BOSE.COM

Installing the Loudspeaker




WARNING: Failure to follow the steps below could lead to an unsafe mounting condition, which could create a falling hazard.


Note: A 6-millimeter hex key is required for proper installation.

Attach the loudspeaker to the bracket by sliding the arms of the bracket into the slots on the loudspeaker, either on the back or side
of the loudspeaker depending on your chosen loudspeaker position (see Installation Options on page 5).

- 2. Insert one of the included M8 screws into the hole on each side of the loudspeaker.
- 3. Tighten the screws using the hex key to secure the loudspeaker to the bracket.
- 4. Insert one rubber cap into the hole on each side of the loudspeaker.








Rotating the Logo

You can rotate the Bose logo to align with your loudspeaker orientation. To rotate the logo, first remove the grille by removing the three screws on each side of the grille.

With one hand, press the button on the back of the grille. Rotate the logo with the other hand. The logo can be rotated clockwise or counterclockwise.

Once you've rotated the logo to your desired orientation, replace the grille and secure it into place with the six screws.

Note: Do not pinch the button inward unless you intend to remove the logo.



Safety and Regulatory Compliance

The Bose DesignMax DM10S-SUB loudspeaker has passed testing and complies with the following specifications and uses:

Listed to ANSI/UL 1480A-2016, Speakers for Commercial & Safety Professional Use

General-Purpose Use - UL Category UEAY, File Number S 5591 Control Number 3N89

Suitable for installation using Class 1, Class 2, Class 3 wiring methods in accordance with NFPA 70, National Electrical Code, 2017, Article 640

The DesignMax DM10S-SUB loudspeaker has been designed to the requirements defined in the following European regulatory specification for combination systems:

Tested to IEC60268-5, 2007