Superlux

HDB387

In-Ear Wireless Stereo Headphones 無線立體聲入耳式耳機



HDB387

In-Ear Wireless Stereo Headphones

- HDB387 is equipped with 8 mm driver which provides wide and flat frequency response and full spectrum details. Delicate treble and powerful bass delivers immersive music experience!
- The unique Cubic Backcup design of HD387 delivers the same bass reflection effect as the speaker cabinet to provide deeply but clean bass frequency.
- The Ergonomic detachable ear hook design with stability and comfort characteristic will fit you when you exercise.
- Acoustic structural design produces stunning bass Cubic Backcup design delivers the bass reflection effect same as the speaker abinet to provide deeply but clean bass frequency for wide range use.
- 8 mm driver provides wide and flat frequency response and studio-level sound quality.
- Furnished with three different sizes of earplugs and earhooks for every individual to find the best fit.
- Ergonomic design improves the stability on ear and not easy to fall off.

Specifications

Type:

Dynamic, In-ear

Driver:

Ø8mm, neodymium

Sensitivity:

103 dB SPL (1mW) at 1KHz

Frequency Response:

20 - 20,000 Hz

Rated Impedance:

16Ω (copper-coated aluminum wire)

Cable:

0.5 meter

Connector:

Gold plated stereo mini plug

Operating Distance:

10m (free space)

Support:

HFP / HSP / A2DP / AVRCP

Battery:

Standby: up to 130 hrs **Talk time:** up to 8 hrs

Music playtime: up to 6 hrs Charging time: around 2 hrs

Security Precautions

- To avoid long time exposure to high volume, leading to noise-induced hearing damage.
- Should use caution or temporarily discontinue use in potentially hazardous situations.
- Should adjust reasonable volume and time when listening to music.
- Be careful not to turn the volume too high, as you do not hear anything around you.
- 5. Do not recommend using a headset while driving.
- Driving on the way or in a potential dangerous environment, please avoid using deadest to listen to the music, make or receive calls, in order to avoid dispersion attention.
- Should avoid continuing to increase the headset volume, as your hearing need adaptation.
- Keep this product and its accessories out of the reach of children, in order to avoid inappropriate use by children which may pose a fatal danger.
- Should avoid immerse in water during grooming, which may cause damage to the sound quality or the headset.

- Stop using deadest if feel significant discomfort, irritation or other adverse reactions.
- 11. The deadest should not be stored or use at temperatures below -15°C (5°F) or above 55°C (131°F) it may shorten battery life.

Unpacking

Carefully unpack the carton and confirm that the following parts are included:



If any part of the product is damaged, do not use it. Contact your authorized Superlux dealer immediately or Superlux customer service.

Powering on/off

 Keep press the "MF Button" for around 5 seconds, blue light remains bright, the headset enters to pairing mode.

 Keep press the "MF Button" for around 5 seconds, red light switch off.

MF Button —



Charging

- Before charging, make sure the headset has been switched off.
- Plug USB cable into the charging jack of headset; plug other side of USB charging cable into the USB charger or other charging device. Charging will start and the red light remains bright on the headset.
- The headset takes approximately 2 hours for fully charged, blue light remains bright or red light switch off after charging completed.

Checking the battery

- While the headphones are in use, the battery indicator blinks red and with sound prompt when the battery needs charging.
- If you are connected to an Apple device, the device displays the headphone battery charge level near the upper right corner of the screen.

Indicator

Indicator activity	System state
Blinking blue/red	Ready to pair
Blinking blue	Connected
Blinking Red	Need to charge

Choosing the correct earplugs and ear hooks

- 1. For optimal audio performance, it is important to choose the correct size of earplugs and ear hooks.
- 2. Select the size that gives you the best comfort and fit in each ear. To determine the best fit, you may need to try all three sizes. You may need a different size for each ear.

Fitting the earbuds to your ear

The HDB387's earplug allows the earbud to rest comfortably and securely in your ear. The tip wing fits just under your ear ridge.

- Insert the earbud so the HDB387's earplug gently rests in the opening of the ear canal.
- 2. Tilt the earbud back and tuck the earplugs wing under the ear ridge until it is secure.



To pair your headset with your mobile phone

- Keep distance of the headset and mobile phone within 1 meter, the closer, the better.
- Switch on the headset, ensure the headset entered to pairing mode, the LED indicator light blinking blue/ red.
- Switch on BT search function in your mobile phone or other device needs to be connected, the mobile phone will display the model "Superlux B01".
- 4. Select model "Superlux B01" (some mobile phone need to enter the password "0000" or "1111" to pair the headset), your headset will automatically connect with your mobile phone, blue light blinks.

IMPORTANT: Generally, pairing time of headset has limited to 150 seconds, if the blue light has been off or blinks, means headset pairing mode has stopped. If pairing remains unsuccessful, please retry step 1 to 4 again.

Reconnect the paired headset with the mobile phone.

- Keep distance of the headset and mobile phone within 1 meter.
- Keep press the "MF Button" until the blue light blinks, the headset will automatically reconnect with your mobile phone.

CARE AND MAINTENANCE

Storing

- · Turn off the headphones when not in use.
- Before storing the headphones for more than a few months, fully charge the battery.
- · Place the headphones in the carry case for storage.

Cleaning


Your headphones may require periodic cleaning.

- Earplugs and Ear hooks: Remove the tips from the earbuds and wash them with a mild detergent and water. Make sure you thoroughly rinse and dry the tips before attaching them to the earbuds.
- Headphone nozzles: Clean only with a dry, soft cotton swab or equivalent. Never insert any cleaning tool into the nozzle.

9

HEADPHONE CONTROLS





Media playback and volume functions

Function	What to do
Play/Pause	Press ►II
Skip Forward	Press ➤
Skip Backward	Press 🙀
Volume Up	Press "+"
Volume Down	Press "-"

Media playback and volume functions

Function	What to do
Answer a call	Press O
End a call	Press O
Decline an incoming	Keep press O around 2 seconds
call	
Activate voice control	Keep press O around 2 seconds (Mobile phone need to support this function)
Last call redialing	Double press O
Call waiting (Mobile phone needs to support this function	·If there is another incoming call while you are answering incoming call 1, press the "MF Button" once to drop the incoming call 1, and press the "MF Button" again to answer the incoming call 2.
	·If there is another incoming call while you are answering incoming call 1, keep press the "MF Button" for around 2 seconds, then release, to keep the incoming call 1 and answer incoming call 2.
	·If you are answering incoming call 2, want to change to incoming 1, can keep press the "MF Button" for around 2 seconds, then release, you can swithch back to incoming call 1.
	If you are answering incoming call 2, and keep the call 1, press the "MF Button" once to drop call 2, then resume call 1. (Mobile pgone need to support this function.

TROUBLESHOOTING

Problem	What to do
Headphones don't turn on	Power on the headphones.
	Charge the battery
Headphones don't pair with device	 On your device: Turn the BT feature on and then off. Delete your Superlux B01 headphones from the list on your device. Pair again.
	 Move your device closer to the headphones and away from any interference or obstructions.
No sound	 Power on the headphones and charge the battery.
	 Increase the volume on your headphones and device.
	Press the Power button to hear the connected device, Make sure you are using the correct device.
	 Move your device closer to the headphones and away from any interference or obstructions.
	Use a different music source.
	 Pair a different device.

Problem	What to do
Poor sound	 Use a different music source.
quality	 Pair a different device.
	 Move the device closer to the headphones, and away from any interference or obstructions.
	Clear any debris or wax buildup from the earbuds and headphone nozzles
Headphones don't charge	Make sure the connector on the cable is correctly aligned with the connector on the headphones.
	 Secure both ends of the USB cable.
	If your headphones have been exposed to high or low temperatures, let the headphones return to room temperature and then try charging again

- · HDB387入耳式耳機採用8mm驅動單元,可產生寬廣平 坦的頻率曲線,並提供完整的音域細節。細膩的高音配 上有力的低音,給人身歷其境的音樂體驗!
- · 立體後腔設計提供耳機如音箱導向孔效果,使低頻更為 扎實、乾淨
- · 符合人體工學的可卸式耳掛設計,牢固舒適,適合運動 時佩戴!

無線立體聲入耳式耳機

- · 聲學結構設計產生震撼低
- · 立體後腔設計提供耳機如音箱導向孔效果,使低頻更 為紮實、乾淨
- · 8mm驅動單元提供寬廣平坦的頻率響應及錄音室等 級音質
- · 3組不同尺寸的耳塞與耳掛,可根據個人需求使用
- · 人體工學設計增加配戴穩定性,不易脫落

技術規格

聲學結構:入耳式

驅動單元:Ø8mm,釹鐵

靈敏度: 103 dB SPL (1mW) at 1KHz

頻率響: 20 - 20,000 Hz

額定阻抗:16Ω(銅包鋁線)

線材:雙邊出線55cm 接頭:3.5mm鍍金接頭

工作範圍:10米 (無障礙環境下)

電量:

待機時間:約130小時

通話時間: 約8小時

音樂播放時間:約6小時

充電時間:約2小時

注意事項:

- 應盡量避免長期暴露在過高音量下,以導致噪音引起的聽力受損。
- 2. 如所環境有潛在危險,請暫停使用耳機,以確保安全。
- 3. 應合理控制聆聽耳機時的音量和時間。
- 不應把音量調得太高,導致您聽不到四周的聲音。如果 出現耳鳴或將音量調得太高,請將音量調低。
- 5. 不建議在駕駛時使用耳機。
- 6. 在駕駛途中或有潛在危險的環境中,請避免用耳機聆 聽音樂,撥打或接聽電話,以免分散注意力。
- 7. 聽覺在適應音量時,應避免持續調高耳機音量。
- 應將耳機放置于兒童無法接觸的地方,避免兒童不當使用,造成致命危險。
- 9. 在梳洗時應避免耳機進水,以免導致耳機損害音質或 耳機。
- 10. 如果使用耳機感覺明顯不適,有刺激感或其他不良反應,應立即停止使用。
- 11. 不應將耳機儲存或使用于溫度低于-15°C (5°F)或高于55°C(131°F)的環境,否則或會縮短耳機或電池壽命。

開箱

小心地拆開包裝箱並確認是否含有以下部件:




如果產品部分損壞,請勿使用。請立即連絡 Superlux 授權經銷商或 Superlux 客戶服務處。

打開/關閉電源

· 開啟無線接收裝置: 按住多功 能按鍵約 3~5 秒, 直到指示燈 轉為紅燈放開即可。

· 關閉無線接收裝置: 按住多功 能按鍵約 3~5 秒,直到指示燈 紅燈熄滅即可。

多功能按鍵



充雷方式

- 1. 充電前,請先關閉接收器
- 2. 將充電線插入USB 充電孔,另外一端插入充電器裝置。
- 3. 耳機充電需要約2 小時,

檢查電池

- 當正在使用耳機時,若電池需要充電,電池指示燈會閃 爍紅色並且發出提示音。
- 若將耳機連接至一台Apple 裝置,裝置會在螢幕的右上角顯示耳機電池電量。

指示燈

指示燈活動	系統狀態
閃爍的紅藍光	準備配對
閃爍的藍光	已連接
閃爍紅色	需要充電

選擇正確的耳塞

- 1. 選擇正確尺寸的耳塞對於獲取最佳音訊效能至關重要
- 2. 撰擇可帶給您最佳舒適感並適合每只耳朵的尺寸。要想 確定最合適的耳塞,您可能需要試戴全部三個尺寸。您 的每只耳朵可能需要不同的尺寸。

將耳機正確地戴在耳朵上

固的佩戴在您的耳朵內。

- 1. 插入耳機,使HDB387 耳寒恰好 佩戴在耳道開口處。
- 2. 將耳機向後傾斜,將耳塞塞到耳 甲下, 直至牢固固定。



配對您的裝置

- 請將耳機和手機(或其他用作連接的裝置)的距離控制 在1米範圍內,越近越好。
- 將耳機開機,並確認已經進入配對模式,此時紅藍燈 交叉閃爍。
- 打開手機或是其他所需連接的裝置的BT搜索功能,手機上會顯示已經找到型號 "Superlux B01"
- 4. 選擇型號 "Superlux B01"(部分手機須輸入 "0000" or "1111"作為配對密碼),耳機會自動與 手機連接藍燈閃爍

注意: 耳機配對一般為 150秒,如果藍燈熄滅或是閃爍,表示配對狀況已經停止。如果您仍未配對成功,請重複1至4步驟再次配對

斷開耳機與手機連接

關閉耳機,或關閉手機的連接功能。

重新連接以配對的耳機

- 請將耳機和手機(或其他用作連接的裝置)的距離控制 在1米範圍內,越近越好。
- 2. 長按 "多功能鍵 "至藍燈閃爍,耳機會自動與手機重 新連接

耳機狀控制項



媒體播放和音量功能

功能	措施
撥放/暫停	按Ⅶ
快轉跳過	按▶₩
倒轉跳過	按₩
音量上調	按 +
音量下調	按 -

呼叫功能

呼叫切能	
功能	措施
接聽呼叫	按〇
結束呼叫	按〇
拒絕接聽來電	長按〇約2秒。
啟動語音控制	長按 O 約2秒。(需手機支持此功能)
末位重播	雙擊○
三方通通話	1.通話時,遇有第2個來電,單擊"多功能鍵"掛
	斷第1個通話,在單擊,可接聽第2個來電。
	2.通話時,遇有第2個來電,長按"多功能鍵"約
	2秒放手,可接上第2個來電,並保留第1個通
	話。當第2個在通話,第1個通話在保留,長按"
	多功能鍵"約2秒放手,可切換到第1個通話來。
	3.當第2個在通話,第1個通話在保留,單擊"多
	功能鍵"可掛掉第2個通話,並恢復第1個通話(
	需手機支持此功能)

維護與保養

存儲

- 在不使用時關閉耳機。
- · 若數月不使用耳機,放置前將電池充滿電。
- 將耳機存放在攜帶型包裝袋中。

清潔

您的耳機可能需要定期清潔。

- 耳塞:將耳塞從耳機上取下,然後使用中性清潔劑和水沖洗。確保在將它們安裝到耳機上之前對其進行了徹底的沖洗和乾燥處理。
- · 耳機出音孔: 只能使用乾燥、柔軟的棉質抹布或類似物 品清潔。請勿將任何清潔工具 插入出音孔。

疑難排解

問題	措施
耳機未打開	· 打開耳機電源
	・給電池充電
耳機未與 裝置配對	· 在您已啟用的裝置上: -打開牙功能再關閉 - 從裝置的清單中刪除您的 Superlux B01 耳機。再次配對
	· 將裝置靠近耳機,遠離其他干擾或 障礙物

沒有聲音	·打開耳機電源,然後為電池充電
	・提高耳機和裝置的音量
	·按電源/按鈕,收聽已連接的裝置。確 保您使用的是正確的裝置
	· 將裝置靠近耳機,遠離其他干擾或 障礙物
	· 使用不同的音樂來源
	・配對另一個裝置
音質差	· 使用不同的音樂來源
	· 配對另一個裝置
	· 將裝置靠近耳機,遠離其他干擾或 障礙物
	· 清除耳機和耳機出音孔上的碎屑 和耳垢
耳機無法充電	· 確保線的連接器與連接器正確對齊。
	·固定USB線的兩端
	·如果您的耳機曾被暴露在高溫或低 溫環境中,等待耳機恢復室溫,然後 再次充電

Contact

Marketing and sales

Superlux Taiwan +886-2-26931323 sales@superlux.com.tw support@superlux.com.tw

Manufacturing & logistics Superlux Enterprise

Development(Shanghai)Co., Ltd.

連絡我們

中国地区营销和业务 旭广企业发展 (上海)有限公司 021-69223756 shsales@superlux.com.tw support_cn@superlux.com.tw

國際營銷和業務 Superlux 舒伯樂 台灣 +886-2-26931323 sales@superlux.com.tw

www.superlux.com.tw