

Saramonic

Sound.Remarkable. 

NoiseWall

Wireless Active Noise-Cancelling Headphones

无线主动降噪立体声耳机

SR-BH900

This manual is for reference only. Please refer to the actual product for the specific functions and appearance of the product. Please read it carefully before using this product and keep it in a safe place for future reference.

本手册仅供参考。产品具体功能及外观请以实物为准。使用本产品前请仔细阅读，并妥善保管，以备查阅。


Packing List




NoiseWall SR-BH900




Carrying Case




USB-C to Micro USB Charging
Cable (60cm)




3.5mm Audio Cable (1m)



User Manual











Plug Adaptor for
In-flight Use



- a. Charging Indicator
- b. Microphone
- c. ANC Indicator
- d. Pairing Indicator

- 1. ANC Button/
Ambient Sound Button
- 2. Type-C Charging Port
- 3. Voice Assistant Button
- 4. Power Button
- 5. Touchpad
- 6. 3.5mm AUX Port

LED Indicator Status

Equipment status	Indicator light	Icon	Voice prompt
Power on	Red & blue indicators flashing alternately		Power on
Power off	Red indicator flashing 1s		Power off
Bluetooth connected	Blue indicator flashes 1 time / 5s		Connected
Charging	Indicator solid red		/
Fully charged	Indicator solid blue		/
Low battery	Red indicator flashing for 2 times / 1s		Battery low
Pairing	Red & blue indicators flashing alternately		/
Playing	Blue indicator flashes 1 time / 5s		/

Specifications


Model	SR-BH900
Bluetooth Version	Bluetooth V5.0
Supported Audio Format(s)	aptX, SBC, and AAC audio codecs
Operating Distance	10m
Noise Reduction Rating	28dB
Battery Capacity	750mAh
Charging Time	about 2.5 hours
Playtime	approx. 17 hrs (BT ON, ANC ON) approx. 25 hrs (BT ON, ANC OFF) approx. 41 hrs (BT OFF, ANC ON)
Standby time (BT connected)	approx. 26 hrs (ANC ON) approx. 120 hrs (ANC OFF)
Dimensions	210*165*80mm
Weight	about 260g



Note: BT=bluetooth, ANC=active noise canceling


① Power Button

- Power on: press and hold for 4s.
- Power off: press and hold for 4s.
- Pairing Mode: If not connected with any devices, the headphone will enter pairing mode automatically. If connected with a device, power off the headphone, press and hold the power button for 8s, the voice prompts changes from "Power on" to "Pairing" to "Du", the headphone will enter pairing mode.
- Answer / End a call: short press.
- Decline an incoming call: double short press.



② Voice Assistant Button

Voice assistant: press and hold for about 1.5 seconds.



③ ANC Button (Active Noise-Cancelling)

- (Short press in any status to switch the mode)
- Turn on the ANC Mode: ANC Indicator solid green ●
 - Turn on the Ambient Sound Mode: ANC Indicator solid white ●
 - Turn off the ANC Mode: ANC Indicator light off

④ Touchpad

- Volume up: slide up
- Volume down: slide down
- Next song: slide right
- Last song: slide left
- Play / Pause: double click





⑤ Charging Port

(Charging with Type-C charging cable)


Headphone status	Voice prompt	Indicator
Low battery	Battery low	Red indicator flashes 2 times /s
Low battery and powered off automatically	-	Red indicator flashes 1s and turn off

⑥ 3.5mm AUX Port

In any mode, connect headphone with device using supplied audio cable via AUX port. The headphone will switch to AUX mode automatically, and Bluetooth mode will automatically turn off.

In AUX mode, the Bluetooth, voice assistant button and touchpad will be disabled, the ANC button is still available.


AUX mode needs no battery.




1. Pairing

- ① If not connected with any devices, the headphone will enter pairing mode automatically after powered on. If connected with the 1st device, power off the headphone, press and hold the power button for 8s, the voice prompts changes from "Power on" to "Pairing" to "Du", the headphone will enter pairing mode, and can be pairing with the 2nd device.
- ② Indicator light flashing red and blue alternately.
- ③ Search the Saramonic BH900 on the Bluetooth list of the second device, select it and connect the headphone.
- ④ Voice prompt "connected".

Notes: The pairing mode will last for 10 minutes. If there is no Bluetooth connection with any device for more than 10 minutes, the headphone will automatically turn off.



2. Wear the headphones and adjust to a comfortable size and position as below image.



Connect an Additional Bluetooth Device

1. Connect the headphone with the first device.
2. Turn off Bluetooth on the first device, the headphone will enter pairing mode automatically again.
3. Search the Saramonic BH900 on the bluetooth list of the second device, select it and connect the headphone.
4. Go back to first device, select Saramonic BH900 and connect.
5. Now the headphone is connecting with two devices simultaneously.

Q: Failed to connect devices with headphones?

A: Please ensure your headphones in pairing mode. Then delete the pairing record on the Bluetooth devices and reconnect with headphones.

Q: Failed to turn on the headphones?

A: Please check the battery status of your headphones.

Q: Can I replace the battery in the headphones?

A: No. These headphones use a built-in non-detachable Li-Polymer battery which can not be replaced.

Q: Can I use the headphones while driving?

A: For your safety, we strongly recommend you do not use headphones while driving in order to avoid distractions.

Q: Why is the connection sometimes disconnected within 10 meters?

A: If there are many WiFi routers, 4G signals, high-power electrical appliances and etc when using, it may be interfering with the Bluetooth connection. It can be solved by changing the environment or reconnecting.

Q: No sound from my computer or mobile phone?

A: Please check if the output channel of your computer supports the A2DP profile. Also check the volume settings on your headphones and computer/mobile phone.

Q: Why am I unable to control the volume of a track playing on my mobile phone's APPs?

A: The configurations of various application softwares are different, the headphones may not be completely compatible with some APPs.

Q: What should I do if the Bluetooth connecting function cannot close or open?

A: Please reset the Bluetooth function of the headphones by inserting an audio cable into the audio port and removing it.

Q: Why does Bluetooth turn off when I connect an audio cable?

A: This is one of BH900 special features. When the user inserts an audio cable into the audio port, all Bluetooth feature buttons temporarily stop working and Bluetooth turns off. The Bluetooth will be available again when pulling out the audio cable.

After-sales and Supports

According to the relevant laws and regulations of consumer electronic products and the actual the situation of the industry, the following after-sales service regulations are formulated to provide consumers with satisfactory after-sales services:

1. Warranty certificate mainly includes:

warranty card and sales certificate.

2. After-sales service scope:

- During the warranty period of the product, the company will be responsible for providing free maintenance for any failure caused by the quality problem of the product itself under normal use without disassembly and repair;
- For products beyond the warranty period, the warranty certificate shall be issued and the maintenance fee shall be paid. If any spare parts are needed for repair cost for the spare parts would be born by the purchaser; please avoid repair and replace when the product is not tested by Saramonic after-sales department;
- Once the warranty certificate is altered, the warranty will become invalid immediately;
- The warranty certificate of the product shall be properly kept by the consumer and shall not be supplemented if lost.

3. Warranty Period:

- Within one year after purchasing this product, there are quality problems in normal use (non-human damage) without disassembly and repair;
- Consumers who have quality problems in normal use (non-human damage) within 7 days from the date of purchase, without repair, can enjoy the replacement service; 1-year warranty (including all accessories) from the date of issuing the sales certificate;

4. Regulations on invalidation of the warranty during the warranty period:

4.1 In the following cases, the warranty is invalid, but the maintenance service is provided, the labor fee and parts fee are charged:

- (1) any damage to accessories caused by improper use, maintenance and storage of consumers;
- (2) damage caused by force majeure, such as natural disasters.

4.2 In the following cases, the company will refuse to provide maintenance services or provide charged maintenance services:

- (1) fail to provide holograms on product packaging box;
- (2) the contents of the holograms are altered or illegible;
- (3) It is unable to provide the product warranty card or the content recorded in the warranty card is inconsistent with the product, or the content is altered or illegible;
- (4) headphones that have been removed by any unauthorized person of Shenzhen Jiayz Photo Industrial, Ltd. (such as changing wires, removing voice coils, etc.);
- (5) there is no sales voucher or the content of the sales voucher is inconsistent with the product.

5. We will not provide warranty service in the following cases After our inquiry:

if we find that your repair products are not our products, we will refuse to provide warranty service, or double the maintenance fee. Please attach the warranty certificate when you send the headphones to our company for repair. If you don't have any certificate, our company will handle it as parallel imports.

Safety Instructions

1. Read, follow, and keep these instructions.
2. For the best possible experience, always use the product as described by the manufacturer.
3. Always handle your headphones with care and protect them from external damage.
4. Clean your headphones using a soft dry cloth. Never use water, cleaning detergent, leather polish or other substances as they may damage your headphones permanently.
5. Avoid exposure to extreme conditions such as very cold or hot temperatures, magnetic fields or damp environments.
6. Listening to music at high volume for prolonged periods can cause permanent damage to your hearing.
7. Contains small parts and are not suitable for children age three (3) and below.
8. The headphones contain magnetic material.
9. The headphones contain a Lithium battery. If misused or damaged it can become a hazard and is at risk of explosion.
10. Should a battery cell leak, Please do not allow the liquid to come in contact with skin or eyes.
11. The headphones must be switched off before boarding an aircraft.
12. The headphones must not be disposed of with regular household waste. Please dispose of in accordance with local regulations.
13. Please do not use your headphones in the immediate proximity (10 cm) of a pacemaker.
14. Please do not subject the product and included accessories to abnormal wear and tear.
15. Please do not expose the headphones to temperatures below -20°C or above $+45^{\circ}\text{C}$.
16. Please do not charge the headphones in temperatures below 0°C or above $+45^{\circ}\text{C}$.
17. Please do not attempt to burn the headphones. The battery could explode causing injury and death.
18. Please do not attempt to open, modify, disassemble, repair, or in other ways, access the internal structure of the headphones. They are not user-serviceable.
19. Please do not use or store the headphones near a vehicle airbag due to injury risk.
20. Please do not use headphones while driving, jogging, or walking through traffic areas. Headphones effectively isolate external sound and noise, which means that when in use, you might not be able to hear your surroundings.
21. Please do not drop, sit on or cause other unusual impacts on the headphones.
22. Please do not expose to fire, water or high voltage equipment.
23. Please do not expose the product to rain, or moisture.
24. Please do not use the headphones near water, bathtubs, sinks, saunas, pools, other liquids, or moist areas.